



Single Action Option



ITEM	PART NO.			DESCRIPTION	QTY
	SA30	SA40	SA52		
51.	1014-1099	1014-1099	1014-1099	RUBBER BUMPER	1
52.	1014-1100	1014-1100	1014-1100	END CAP FASTENER	4
53.	1024-1041	1029-1043	1014-1067	CLAMP PLATE	1
54.	1024-1036	1029-1036	1014-1024	RETENTION RING	1
55.	1024-1073	1029-1104	1014-1193	END CAP	1
56.	1051-1068	1052-1068	1051-1068	LOCK NUT	4
57.	0701-1007	0701-1007	0701-1007	WASHER	4
58.	0768-1022	0768-1022	0768-1022	BREATHER	1

Drawing repeated for reference



Installation

When unpacking a Tolomatic cable cylinder, BE EXTRA CAREFUL NOT TO SCRATCH OR MAR THE NYLON COVERING ON THE CABLE. The cylinder may be mounted using the bolt holes in the head. When attaching the cable bracket to the driven mechanism, be sure it is in perfect alignment and that it does not deflect the cable to the side. Misalignment can cause excessive seal wear.

Pretensioning and proof-loading instructions: All double-acting cable cylinders are shipped without being pretensioned. They must be pretensioned after mounting to insure maximum service life of the device. There are two types of stretch in cable— constructional and elastic. The constructional stretch is removed by proof-loading of the cable. The elastic stretch is removed by proper pretensioning of the cable.

Proof-loading of cables (for cylinders without Auto Tensioners)

1. Tighten the bracket terminal lock nuts equally with a torque wrench to torque requirements listed in Table A.
2. Let set for 30 seconds.
3. Loosen lock nuts to remove tension. (But leave them tight enough to eliminate any slack.)
4. Follow Pretensioning Instructions.

TABLE A: TORQUE TO PROOF-LOAD THE CABLE	
MODEL	REQUIRED TORQUE
CC30, CC40, CC52	220 INCH-POUNDS (23.73 NEWTON-METERS)

Pretensioning of cables:

1. Block the load some distance from the end of travel to keep cylinder from bottoming.
2. Apply pressure that is 15-20 percent higher than actual pressure needed to move the load.

NOTE: Load pressure is defined as the actual pressure required to move the load. When the load is stopped externally before the piston bottoms, the relief valve or regulator setting becomes the load

pressure. When pressurized, one cable becomes tight and the other becomes slack. Manually adjust out the slack. Release the pressure. Block the load on the opposite side and pressurize the other port. Repeat the manual adjustment on the other cable. Release pressure and remove blocks. Return the regulator or relief valve to the original load pressure.

The cylinder is now pretensioned. Additional manual adjustment should not be required. It is suggested however, that the cables be checked periodically.

Alternate Method: If the load cannot be blocked for cable pretensioning as stated above, tighten the bracket terminal lock nuts with a torque wrench to total pretensioning torque as stated in Table B.


TABLE B: TORQUE FOR UNBLOCKABLE LOADS					
MODEL	PRETENSIONING TORQUE	+	STARTING TORQUE OF TERMINAL NUTS	=	TOTAL PRETENSIONING TORQUE
CC30	105.0 IN.-LBS.	+	25.0 IN.-LBS.	=	130.0 IN.-LBS.
	11.86 N-M	+	2.82 N-M	=	14.68 N-M
CC40	187.5 IN.-LBS.	+	25.0 IN.-LBS.	=	212.5 IN.-LBS.
	21.19 N-M	+	2.82 N-M	=	24.01 N-M
CC52	115.0 IN.-LBS.	+	25.0 IN.-LBS.	=	140.0 IN.-LBS.
	12.99 N-M	+	2.82 N-M	=	15.81 N-M

NOTE: For cylinders with Auto Tensioners, the cables must be proof-loaded and pretensioned before pressure is applied to the AT unit.

TO REBUILD THE CYLINDER

1. Remove cable cylinder from machinery.
2. Disconnect Cable (1) from the Clevis (23) and remove Pulleys (14) on both ends of the cable cylinder.
3. Remove one Head (18) from cable cylinder by removing the four Cap Screws (22).
4. Pull Piston (26) towards the open tube end and remove from Tube (27).

Drawing repeated for reference



5. Disconnect Cable Assembly (1) from Piston (26) and pull back through the Head assemblies (18) with their gland seals to remove them.
6. Install new U-cups (25) and O-rings (3) on Piston (26).
7. Being careful not to damage the cable, lubricate gland seals on the Cable Assembly (1) and install the gland seals in the Head assembly (18) and reinstall the Retaining Ring (2).
8. Push the Piston (26) back into Tube (27) by gently tucking in the U-cup (25) with a screwdriver or pencil. Mount head back on cylinder with Socket Head Cap Screws (22). Replace the Pulleys (14) and connect Cable Assembly (1) to Clevis (23).
9. Operate cable cylinder back and forth by hand several times to be sure it is properly assembled before reconnecting air or hydraulic service.
10. Reinstall cable cylinder on machinery.

IMPORTANT NOTE: Apply (Blue) Loctite® #242 or equivalent to threaded cable terminal before connecting to the piston.

MAINTENANCE


Keep the cylinder as clean as possible around pulleys, glands, etc. Pneumatic service should be adequately lubricated with SAE 10 or 20 grade non-detergent oil. Pulleys have permanently lubricated bearings and will require no maintenance. Check the cylinder's cables periodically to help prevent premature or unexpected failures.

Your Tolomatic Cable Cylinder will give you many cycles of trouble free service. However, should a leak occur, a rebuilding kit may be obtained which enables you to replace all the seals in a cylinder to return it to normal operating condition.

NOTE: Every Tolomatic Cable Cylinder has its stroke length indicated on the identification tag shipped with the cylinder. Refer to this stroke measurement when ordering replacement parts for the cable cylinder.

Should the tag be missing, measure the length of the cylinder including the heads at both ends. If there are no switches present on the cylinder, check the piston for a magnet to see if it is a Reed Switch model. If it is, consult the Tolomatic Cable Cylinder catalog dimensional drawings for "stroke-plus" length and subtract 1.62 inches for cylinders with 1/2-inch 3/4-inch and 1-inch bores and .375 inches for all larger bore Reed Switch models to determine the stroke length.

AUTO TENSIONER OPTION



All cable cylinder models with Auto Tensioner units should be plumbed with a separate, non-fluctuating pressure source which is a set percent-age of the actual operating pressure.

AUTO TENSIONER

ITEM	PART NO.	DESCRIPTION	Quantity									
			CC30	CCM30	CCS30	CC40	CCM40	CCS40	CC52	CCM52	CCS52	
33	1014-1138	SEALED BALL BEARING	2	2	2	2	2	2	2	2	2	2
34	1024-1078	PULLEY	1	1	1	1	1	1	1	1	1	1
35	1014-1137	BEARING SPACER	1	1	1	1	1	1	1	1	1	1
36	1024-1045	HEX HEAD BOLT	1	1	1	1	1	1	1	1	1	1
37	1014-1048	CHECK VALVE GASKET	1	1	1	1	1	1	1	1	1	1
38	1014-1046	CHECK VALVE SPRING	1	1	1	1	1	1	1	1	1	1
39	1014-1047	CHECK VALVE BALL	1	1	1	1	1	1	1	1	1	1
40	1029-1065	TENSIONER HEAD	1	1	1	1	1	1	1	1	1	1
41	1014-1062	O-RING, BUNA-N	1	1	1	1	1	1	1	1	1	1
42	1014-1044	CUSHION ADJUSTMENT NEEDLE	1	1	1	1	1	1	1	1	1	1
43	1014-1049	THREAD SEAL	1	1	1	1	1	1	1	1	1	1
44	1014-1050	HEX HEAD JAM NUT	1	1	1	1	1	1	1	1	1	1
45	1014-1065	PIPE PLUG	2	2	2	2	2	2	2	2	2	2
46	1014-1052	PULLEY SHAFT	1	1	1	1	1	1	1	1	1	1
47	1004-1056	RETAINING RING	2	2	2	2	2	2	2	2	2	2
48	1024-1110	BACK PLATE	1	1	1	1	1	1	1	1	1	1
49	0768-1022	HEX HEAD BREATHER PIPE PLUG	1	1	1	1	1	1	1	1	1	1
50	1024-1109	FRONT TENSIONER PLATE	1	1	1	1	1	1	1	1	1	1
51	1024-8011	SIDE SPACER	2	2	2	2	2	2	2	2	2	2
52	1900-1005	PISTON SHAFT	1	1	1	1	1	1	1	1	1	1
53	0701-1004	O-RING, BUNA-N	1	1	1	1	1	1	1	1	1	1
54	1039-1045	HEX HEAD BOLT	1	1	1	1	1	1	1	1	1	1
55	0774-1003	FLAT WASHER	1	1	1	1	1	1	1	1	1	1
56	1024-8025	TIE PLATE	1	1	1	1	1	1	1	1	1	1
57	0925-1039	CAP SCREW	4	4	4	4	4	4	4	4	4	4
58	1900-1009	SOCKET HEAD CAP SCREW	4	4	4	4	4	4	4	4	4	4
59	1024-1107	TENSIONER TUBE	1	1	1	1	1	1	1	1	1	1
60	1024-1106	PISTON	1	1	1	1	1	1	1	1	1	1
61	1024-1105	O-RING, BUNA-N	1	1	1	1	1	1	1	1	1	1
62	1024-1104	O-RING, BUNA-N	1	1	1	1	1	1	1	1	1	1

BORE SIZE (IN.)	% OF LOAD PRESSURE	BORE SIZE (IN.)	% OF LOAD PRESSURE
0.75	22%	4.00	96%
1.00	40%	5.00	75%
1.50	86%	6.00	57%
2.00	32%	8.00	102%
2.00 (500 PSI)	24%		
2.50	51%		
3.00	54%		

In the above table, load pressure is defined as the pressure required to move the load, NOT the regulated pressure (pneumatic) or the relief valve setting (hydraulic).

NOTE: If the load will be stopped mechanically prior to the piston bot-toming, then the regulator pressure or the relief valve setting must be considered to be the load pressure.

If the application is hydraulic, a pressure-reducing valve must be used to ensure a non-fluctuating pressure source to the tensioner(s) or the pres-sure source must be an independent circuit that will maintain the required differential.

When installing cable cylinder models with Auto tensioner units, take up the cable slack manually according to the pretensioning instructions under General Installation and Maintenance


AUTO TENSIONER KITS

PART NO.	DESCRIPTION	QUANTITY								
		CC30	CCM30	CCS30	CC40	CCM40	CCS40	CC52	CCM52	CCS52
1024-9115	AUTO TENSIONER KIT CC30, CC40, CC52	1	1	1	1	1	1	1	1	1
1024-9127	AUTO TENSIONER KIT CC30, CC40, CC52 – 3 PORTED HEAD	1	1	1	1	1	1	1	1	1

REED SWITCHES

NOTE: Form A Reed Switches should not be used in TTL logic circuits. A voltage drop caused by the L.E.D. indicator will result. For applications where TTL circuits are used, please contact Tolomatic.

WARNING: An ohmmeter is recommended for testing Reed Switches. NEVER use an incandescent light bulb as a high current rush may damage the switch. Reed and TRIAC switches are only recommended for signalling position, not directly powering solenoids. For shifting a solenoid, a relay or resistor is recommended instead of the switch. Switch ratings must not be exceeded at any time



CONFIG. CODE ORDERING		
MOUNTING HARDWARE & FE CONN. INCLUDED		
ITEM	CODE	DESCRIPTION
19.	BT	SWITCH KIT, REED, FORM C, 5M
	BM	SWITCH KIT, REED, FORM C, QD MALE CONN.
	RT	SWITCH KIT, REED, FORM A, 5M
	RM	SWITCH KIT, REED, FORM A, QD MALE CONN.
	CT	SWITCH KIT, TRIAC, 5M
	CM	SWITCH KIT, TRIAC, QD MALE CONN.

ITEM	PART NO.	DESCRIPTION	QUANTITY						
			CC30, SA30	CCM30, SAM30	CCS30, SAS30	CC40, SA40	CCM40, SAM40	CCS40, SAS40	CCM52, SAM52
22.	1075-1019	MAGNET		1					
	1001-1202	MAGNET				1			
	1075-1019	MAGNET						1	

NOTE: When ordered female connector & all mounting hardware is included





To Order Retrofit Kits

All Switch Kits come with 1 switch and mounting hardware.

Retrofit ordering method: **S** **W** **□** **□** **□** **□**

EXAMPLE: **S** **W** **CC** **40** **RT**
 Switch Kit Model Size Switch Type Code

Universal Switch Wiring Diagrams and Label Color Coding



NOTE: The side of the switch with the groove indicates the sensing surface. This must face toward the magnet.

For complete Reed and TRIAC Switch Performance Data, refer to the [Tolomatic Pneumatic Products Catalog](#).

Loctite® is a registered trademark of the Loctite Corporation, www.loctite.com
 Viton® is a registered trademark of the E.I. Du Pont de Nemours Co., www.dupont.com

SWITCH TYPE CODE	
BT	FORM C REED SWITCH WITH 5-METER LEAD
BM	FORM C REED SWITCH WITH 5-METER LEAD AND QD
RT	FORM A REED SWITCH WITH 5-METER LEAD

SWITCH TYPE CODE	
RM	FORM A REED SWITCH WITH 5-METER LEAD AND QD
CT	TRIAC SWITCH WITH 5-METER LEAD
CM	TRIAC SWITCH WITH 5-METER LEAD AND QD



3800 County Road 116, Hamel, MN 55340 USA
 http://www.Tolomatic.com • Email: Help@Tolomatic.com
 Phone: (763) 478-8000 • Fax: (763) 478-8080 • Toll Free: 1-800-328-2174



All brand and product names are trademarks or registered trademarks of their respective owners. Information in this document is believed accurate at time of printing. However, Tolomatic assumes no responsibility for its use or for any errors that may appear in this document. Tolomatic reserves the right to change the design or operation of the equipment described herein and any associated motion products without notice. Information in this document is subject to change without notice.